



9. Sew down the bias from the front, parallel to the first seam line about 0.2cm from the seam. Make sure the back of the bias is caught by the stitches.



10. Now repeat for the armhole seams. First, sew down from the front.



11. Fold bias over to cover the raw edges, clip in place and sew.



This is what you should have after covering all the curves with bias.



12. With the right side facing up, flip one side of the strap over. Align the top of the strap to the top of the apron front. Clip in place.



13. Repeat for the other side. Clip and baste in place.



14. Take the facing piece, with the right side facing down, and align the top edge to the top of the apron. The straps are sandwiched in between the facing and the apron pieces.



15. Sew 1cm from the top edge.