



1. Cut out pattern pieces



2. Flip one side piece over, align side seams, with fabrics right sides facing. Clip in place.



3. Sew side seams, repeat for the other side. This is what you should have after sewing both side seams. Zig-zag/serge seams to prevent fraying.



4. Lay the bias fabric, right sides facing, with edges aligned.



5. Pin in place.



6. Sew down on the crease line nearest to the outer edge.



7. Flip to the back of the apron, and fold the bias over the raw edge.



8. Pin or clip in place.